

HOW TO USE CAR FIRE BLANKET



1.
CALL TO EMERGENCY NUMBER!
TWO PEOPLE OPEN THE BLANKET AND
PULL OVER THE CAR



2.
PULL THE BLANKET **OVER THE CAR**



3.
MAKE SURE **ALL SIDES ARE CLOSED**
AROUND THE CAR



4.
STEP AWAY FROM THE CAR



5.
FIREFIGHTERS REMOVE THE BLANKET

FIRE IN ELECTRIC CARS

Follow step 1-3. After the fire blanket has been placed tight to the ground, wait 2-3 minutes and listen. If you can hear strong fuzz sounds about every 3-15 seconds, you have a thermal runaway that goes from cell to cell. Leave the fire blanket on, firefighters will remove the blanket. The fire blanket will prevent the fire from spreading elsewhere in the car.